



Manufactured by DepotStar, Inc.

6180 140th Ave NW, Ramsey, MN 55303
Telephone: 763.506.9990 Fax: 763.506.9988
www.alphasystemsaoa.com

How to Adjust the Audio Volume: Classic, Legacy, Ultra & Griffin

Assuming your AUX cable is hooked up to some type of audio interface (speaker, headphones, etc.), first locate the AOA I/F Module. You will see two buttons on either side of the words “Master Volume Set”. One will be to toggle the audio (up) and the other to toggle the audio (down). With power on, hold down the master volume (up) button and you should hear a tone increase to max volume. Press the master volume (down) to hear your tone decrease.

