


# Increasing AOA to Display Indications



Eagle Display

*display shown with all segments illuminated*

## Calibration Set Points:

- 1 - Ground (Zero Set Point)
- 2 - Optimum Alpha ( $1.3 \times V_s$ )
- 3 - Cruise Alpha ( $V_a$  or  $1.9 \times V_s$ )